

Installation Manual

NanaWall CSW75

Folding Center Pivot Frameless System



Table of Contents

Rev. July 31 2017

Sheet


1. Required Tools
2. Rough Opening and Unit Dimensions
3. Headtrack in "kd" Condition
4. Assembly of Headtrack
5. Headtrack Shimming
6. Installation Sequence of Panels
7. Installation Sequence of Panels
8. Panel Alignment and Height Adjustment
9. Drilling Holes for Floor Sockets
10. Centered Pivot Point and Floor Closer Installation
11. Pivot Point Top Track for Single/Double Action End Panel
12. Single / Double Action End Panel Installation
13. Offset Pivot Point and Floor Closer Installation
14. Offset Pivot Point Top Track and Floor Closer Installation
15. Installation of Mortise Cylinder

TOOLS




NanaWall Product Drawing

Metric Tools Supplied in Accessory Box





Rough Opening Dimensions

- after applying all deadloads max. deflection of header the lesser of L/720 or 1/4"
- the weight of a panel with 1/2" glass is 8 lbs/sqft






Unit Dimensions


- leave enough shim space to surrounding unfinished condition




Headtrack in "kd" Condition







Assembly of Headtrack



RHT
Removable
Head
Track




Headtrack Shimming




Installation Sequence of Panels

YOU NEED 2 INSTALLERS TO HANG THE PANELS
Secure and Support the Panels at all Time During the Installation




Step 3 Step 2 Step 1







After adding the hinge pin,
Insert the set screws till they
are tight and then unscrew
a ¼ turn to allow the hinge
pin to rotate freely





Installation Sequence of Panels



Step 4 Step 3 Step 2 Step 1




Please look at sheet 12 of 15 for further instruction




Step 4

Panel Alignment and Height Adjustment




Drilling Holes for Floor Sockets


Step 1




Step 2




Step 3





Step 4




Step 5




Centered Pivot Point and Floor Closer Installation




OPTION 1 Centered




OPTION 2 Bottom Door Closer




Pivot Point Top Track for Single/Double Action End Panel




Single/Double Action End Panel Installation



Steps 1-5 of Sheet 9




Height Adjustment



Width Adjustment

Set Screw to fix axle from Turning




Top Profile of Panel #5


Take off End Cover and Slide Cover to the Side

Offset Pivot Point and Bottom Door Closer Installation



OPTION 3 Offset Pivot Point



OPTION 4 Offset Bottom Door Closer



Offset Pivot Point Top Track and Floor Closer Installation



Installation of Profile Cylinder

